



MONTEREY WALL HEATER


Top Vent

Face Panel Size 16"W x 65³/₄"H x 6"D

Model (1=LPG) **BTU-IN** **AFUE**



25-09822A(1)	25,000	71%	\$ 1,210.00
35-09822A(1)	35,000	70%	1,285.00
50-09822A(1)	50,000	70%	1,775.00

2901 Blower \$ 290.00



Heater Sizing guide

For the mild climate of Eureka you should allow 5BTU per cubic foot of living space.
 For a 600/Sq. Ft set of rooms with 8Ft ceilings the heater output should be about 24,000BTU.
35-09822A 35,000BTU-in → 25,000 BTU-out.



DIRECT-VENT WALL HEATER


Through-The-Wall Vent ♦ Push-Button Pilot

Model (1=LPG) **BTU** **AFUE** **Size**

14-03822(1)	14,000	65%	18"W x 26 ³ / ₄ "H x 7 ¹ / ₂ "D	\$ 1,458.00
22-03822(1)	22,000	67%	32 ¹ / ₈ "W x 28"H x 10 ¹ / ₄ "D	1,762.00
30-03822(1)	30,000	66%	32 ¹ / ₈ "W x 28"H x 10 ¹ / ₄ "D	1,878.00

2302 Blower (22-30,000BTU) \$ 360.00

2303 Blower (14,000BTU) 340.00



Williams Wall Heater Information Sheet





Figure 8 – Typical Vent Installation



NOTE: THESE PARTS ARE SUPPLIED WITH THE FURNACE

